



P021046660 HARNESS KIT INSTALLATION INSTRUCTIONS FOR MODELS PB-770H/T AND PB-760LNH/T

Please retain these instructions for future reference.

Tools Required: T27 Torx bit driver, flat head screw driver, drill with 6mm drill bit, soft hammer

Kit Contents: Instruction Sheet
1 - C061000560 - Small plastic cable tie
1 - C061000550 - Large plastic cable tie
4 - V491000090 - Clips

ASSEMBLY INSTRUCTIONS

1. Pry out center, right, and left clips holding harness to upper frame. Remove worn harness. Discard clips.
2. Remove harness bracket bolts and lock nuts. Retain bolts and nuts for re-use.
3. Push out lower harness clips from bottom right and left frame slots.



SUP22202047

**99922202047
03/14**

4. Push out upper frame harness clips. Remove and discard harness.



NOTE

When harness is properly installed the shoulder curve will be oriented to the outside with ECHO logo visible as shown.



5. Insert upper frame harness clips sideways through upper frame slots and push clips through slots. Rotate clips to retain against the frame wall.



6. Position the harness webbing flush with back pad and at a slight angle as shown. Mark frame through webbing holes with white marker. Repeat for remaining harness.



7. Drill holes in frame using a 6mm drill bit.



8. Tap new clips in place to secure harness webbing tight against the frame. Repeat steps 5-8 for remaining harness.



9. Turn lower harness clips sideways, and insert through bottom frame slots.



10. Install harness bracket bolts and lock nuts. Tighten securely. Harness installation is now complete.



ECHO CONSUMER PRODUCT SUPPORT

If you require assistance or have questions concerning the application, operation or maintenance of this product you may call the ECHO Consumer Product Support Department at 1-800-673-1558 from 8:30 am to 4:30 pm (Central Standard Time) Monday through Friday. Before calling, please know the model and serial number of your unit to help your Consumer Product Support Representative.



ECHO, INCORPORATED

400 OAKWOOD ROAD

LAKE ZURICH, IL 60047

www.echo-usa.com