




PARTS CATALOGUE

ECHO TRIMMER/ BRUSHCUTTER SRM-200CE



SRM-200CE 1




Key No.	Part Number	Q'ty	Description	Key No	Part Number	Q'ty	Description
1- 4	880 516-0922 0	1	Cap, screw	1-20	-100 215-0393 0	4	Knock pin
5	900 242-0501 0	1	Screw 5 x10	21	100 242-0492 0	1	Gasket, crankcase
6	101 514-0932 0	1	Cover, cylinder	22	900 810-3620 1	2	Ball bearing
7	101 011-0932 0	1	Cylinder	23	100 100-0742 0	1	Crankshaft ass'y
8	900 242-0602 0	2	Screw 6 x 20	24	100 142-0031 0	1	Key
9	101 010-0492 0	1	Gasket, cyl.	25	900 242-0503 0	4	Screw 5 x 30
11	101 538-0742 0	1	Plug	26	100 011-0533 0	1	Piston ring
12	890 115-4233 0	1	Label, model	27	100 010-0652 0	1	Piston
13	101 511-4233 0	1	Fan cover	28	100 013-1021 0	1	Piston pin
14	900 600-0000 5	1	Washer 5	29	100 015-0463 0	2	Circlip, piston pin
15	900 605-0000 5	1	Spring washer 5	30	100 014-0652 0	2	Spacer, piston pin
16	900 151-0502 5	1	Bolt 5 x 25	31	100 113-0593 0	1	Bearing, needle
17	900 242-0402 0	4	Screw 4 x 20	34	100 223-0732 0	1	Plug
18	100 213-0553 0	2	Oilseal				
19	100 200-0742 0	1	Crankcase set				

Remarks
19 Includes 20

898 612-4233 0



SRM-200CE 2



Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
2- 5	159 026-0393 0	1	Spark plug (CJ-8)	2-29	900 242-0401 4	2	Screw 4 x14
6	159 011-0343 2	1	Coil spring	31	177 305-0492 0	1	Ratchet ass'y
7	159 012-0343 3	1	Cap, spark plug	32	900 502-0000 8	1	Nut 8
8	156 601-0742 1	1	Module	33	100 615-0492 0	1	Gasket, starter
9	900 242-0402 0	5	Screw 4 x 20	*	177 200-0742 1	1	Starter ass'y
10	156 114-0231 0	1	Grommet	34	-900 241-0401 0	1	Screw 4 x10
15	175 053-0492 0	1	Stopper	35	-177 214-2043 0	1	Washer
16	900 701-0001 2	1	Circlip 12	36	-177 215-0492 0	1	Recoil drum
17	900 819-3620 1	1	Ball bearing	37	-177 226-0393 0	1	Starter rope
18	900 702-0003 2	1	Circlip 32	38	-177 227-0533 0	1	Rope guide
19	175 010-0492 0	1	Clutch case	39	-177 228-0653 0	1	Starter glip
20	175 016-0492 0	1	Clutch boss	40	-177 220-0653 0	1	Rewind spring
21	175 018-0513 0	2	Clutch spring	41	-177 209-0742 0	1	Starter case
22	175 009-0513 0	2	Clutch shoe	42	890 112-2673 0	1	Label, ECHO
23	175 019-0492 0	1	Side plate				
24	156 800-0742 0	1	Flywheel				
25	900 249-0401 6	2	Tapping screw				
26	156 626-0942 0	1	Ignition coil				
27	156 611-0942 0	1	Tube				
28	159 315-0942 0	1	Cover				

Remarks


* Consists of 34 thru 41

SRM-200CE 3

SRM-200CE 4


Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
3- *	145 803-0922 1	1	Muffler assembly	4- 5	131 910-0922 0	1	Bracket, fuel tank
5	-145 871-0922 0	1	Cover, muffler	6	131 920-0922 0	1	Cushion, fuel tank
6	-900 242-0401 0	5	Screw 4 x 10	7	900 242-0401 4	6	Screw 4 x 14
7	-145 809-2843 0	1	Screen holder	8	131 004-0632 0	1	Cap ass'y, f. tnk
8	-145 866-2843 0	1	Gasket	9	-131 315-0502 0	1	Filter
9	-145 862-0922 0	1	Screen	10	-131 314-0632 0	1	Check valve
10	-145 806-0922 0	1	Muffler	11	-131 016-0492 0	1	Gasket, f. tank cap
11	-145 510-0922 0	1	Gasket, muffler	12	131 010-0922 0	1	Fuel tank
12	433 020-0083 0	2	Lock nut 5	13	131 924-0922 0	1	Cushion
13	900 603-0000 5	2	Washer 5	14	131 918-4123 0	1	Bracket, fuel tank
14	101 014-0056 0	2	Stud, muffler	15	890 118-2403 0	1	Label, ECHO
17	130 010-0922 0	1	Gasket	16	132 007-0922 0	1	Fuel pipe (3 x 6 x 135)
18	130 007-0932 0	1	Insulator	17	-132 115-0492 0	1	Grommet
19	900 243-0502 0	2	Screw 5 x 20	19	131 205-0732 0	1	Fuel strainer
20	130 016-0922 0	1	Gasket, carburetor	20	437 411-1983 0	1	Clip
21	123 000-0932 0	1	Carburetor WA 143	Remark: 8 Includes 9, 10 and 11			
22	130 301-0922 0	1	Case, air cleaner				
23	-178 810-2163 0	1	Grommet				
24	178 516-0083 0	1	Spacer				
25	178 515-0922 0	1	Choke shutter				
26	900 242-0504 0	2	Screw 5 x 40				
27	130 310-0653 0	1	Air filter				
29	130 308-0922 0	1	Cover, air cleaner				
30	900 242-0401 8	2	Screw 4 x 18				


Remarks:

* Consists of 5 thru 11
22 Includes 23




Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
5- *	123 000-0932 0	1	Carburetor WA143	5-20	-123 127-1063 0	1	Retaining, spring
1	- (A)	5	Screw	21	-123 172-0432 0	1	Swivel
2	-123 142-0393 0	1	Cover, M. diaphragm	22	-123 127-0393 0	1	Clip, throttle shaft
3	- (A) (B)	1	Diaphragm, metering	23	-123 116-0523 0	1	Valve, throttle
4	- (A) (B)	1	Gasket, M. diaphragm	24	-123 114-0393 0	1	Screw, thrt. valve
5	- (A)	1	Plug, welch	25	- (A)	1	Screen, inlet
6	- (A)	1	Ring, retaining	26	- (A) (B)	1	Pump diaphragm
7	- (A)	1	Screen	27	- (A) (B)	1	Gasket, pump
8	- (A)	1	Plug, welch	28	-123 124-1653 0	1	Cover, fuel pump
9	- (A)	1	Lever, metering	29	-123 110-0393 0	1	Screw, pump cover
10	- (A)	1	Pin, metering lever	30	-123 133-1113 0	1	Spring, idle adjust
11	- (A)	1	Screw, M. lever pin	31	-123 134-0653 0	1	Screw, idle adjust
12	- (A)	1	Spring, meter. lever	32	-UNAVAILABLE	1	Body assembly
13	- (A)	1	Valve, inlet needle				
14	- (A)	1	Spring, H.S. needle				
15	-123 120-0076 0	1	Needle, high speed	Remark: * Consist of 1 thru 32. (A) Use 123 100-0932 0 Carburetor Repair kit (B) Use 123 101-1053 0 Carburetor Diaphragm/gasket kit			
16	- (A)	1	Spring, needle				
17	-123 118-2443 0	1	Needle, idle				
18	-123 113-0393 0	1	Spring, thrt return				
19	-123 117-0932 0	1	Shaft, throttle				

SRM-200CE 6



Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
6- 5	610 013-4233 0	1	Shaft	6-21	351 012-2433 0	1	Grip, handle
6	351 201-0893 0	1	Handle, loop	23	610 210-4233 0	1	Housing, drive shaft
7	900 500-0000 5	3	Nut 5	24	610 217-4233 0	1	Bushing
8	900 600-0000 5	2	Washer 5	25	178 001-0893 1	1	Wire, throttle
9	900 220-0504 0	2	Screw 5 x 40	26	900 502-0000 6	2	Nut 5
11	900 100-0501 8	1	Bolt 5 x 18	27	900 600-0000 6	2	Washer 5
12	699 012-0333 0	1	Spacer	29	890 160-2033 0	1	Label
13	301 207-0893 0	1	Hook	30	890 177-0913 0	1	Label
14	178 024-2433 0	1	Bracket	35	178 076-2723 0	1	Spacer
15	433 020-0083 0	1	Locknut 5	38	163 400-0963 0	1	Switch, ignition
16	900 242-0503 0	1	Screw 5 x 30	39	178 127-2403 0	1	Tube
17	178 110-0533 0	1	Screw				
18	178 043-0693 0	1	Spring				
19	178 010-0563 0	1	Control, throttle				
20	178 048-0563 0	1	Spacer				



Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
7-	610 400-4083 0	1	Housing ass'y gear	7-32	699 010-0913 0	1	Shield
5	-900 220-0501 0	1	Screw 5 x 10	33	900 500-0000 5	4	Nut 5
6	-900 605-0000 5	5	Washer, spring 5	34	699 015-4083 0	1	Bracket, shield
7	-900 600-0000 5	3	Washer 5	35	900 242-0501 0	3	Screw 5 x 10 w/W, SW
8	-900 100-0800 8	1	Bolt 8 x 8	36	900 220-0500 8	2	Screw 5 x 8
9	-900 100-0503 5	2	Bolt 5 x 35	37	890 138-2403 0	1	Label
10	-610 239-0413 0	2	Washer	41	301 000-0753 0	1	Strap
11	-900 806-0001 0	1	Circlip	42	301 305-2433 0	1	Link
12	-900 702-0002 2	1	Circlip	43	898 502-0113 0	1	Pin, split 2 x 22 10 pcs.
13	-900 858-0690 0	1	Bearing, ball 6900	44	897 518-0113 1	1	Rod, locking
14	-900 855-0690 0	1	bearing Ball 6900	45	895 112-0033 0	1	Spanner
15	-610 316-2283 0	1	Washer	46	895 410-0803 0	1	Wrench w/screwdriver
16	-610 317-2283 0	1	Washer	50	890 138-4063 0	1	Label, ECHO
17	-610 300-4233 0	1	Gear set	51	890 177-4073 0	1	Label
18	-610 410-4083 0	1	Housing, gear	52	699 000-4083 0	1	Shield ass'y
19	-900 810-0062 6	1	Bearing, ball 626	53	-699 016-2323 1	1	Cutter
21	-610 310-4083 0	1	Shaft, P.T.O.	54	-699 212-2323 0	1	Protector
22	-900 800-0600 0	1	Bearing, ball 6000	55	-900 242-0501 6	5	Screw 5 x 16
23	-610 315-2283 0	1	Spacer	56	-699 018-4083 0	1	Plate
24	-610 413-2283 0	1	Oilseal				
25	-900 702-0002 6	1	Circlip 26				
26	-610 313-4083 0	1	Plate, adapter				
27	-610 314-0603 0	1	Plate, adapter				
28	-900 511-0001 0	1	Nut 10 L-H				
29	-900 300-2002 2	1	Pin, split 2 x 22				