

## **U-Handle / Blade Conversion Kit** P/N 99944200520 Operator's Manual

MODELS,

# SRM - 2601 Type 1E SRM - 2610 Type 1E

Serial Number 001001 & Up



Read rules for safe operation and instructions carefully. ECHO provides an Operator's Manual and a Safety Manual. Both must be read and understood for proper and safe operation.

X7502091600

89861057739 02/98



## ACCESSORY INSTALLATION

U-Handle / Blade Conversion Kit P/N 99944200520

#### NOTE

Refer to Operation with Blades page 20 in Operator's Manual for correct Accessory / Blade equipment requirements.

## WARNING A DANGER

You must install a U-Handle/Blade Conversion Kit before operating this trimmer using metal blades, otherwise serious injury may result.

## **INSTALL METAL SHIELD**

Tools Required: 8mm x 10mm Open End Wrench, Screwdriver.

Parts Required: Metal Shield, Bracket, 3 - 5mm x 15mm screws w/captivated flat and lockwasher (metal shield to gear housing), 2 - 5mm x 8mm screws, 4 - 5mm nuts, 4 - 5mm lockwashers (bracket to shield and bracket to gear housing).

- 1. If necessary, remove nylon line head and plastic shield.
- 2. Loosely attach bracket (A) to shield (B) and attach to bottom of gear housing (C) with screws and nuts provided. Tighten all attaching hardware.

### Install Blade

Tools Required: Locking Tool, scrench.

Parts Required: 1 - 20mm Upper Fixing Plate, Grass Blade (69600120330), Brush Blade (69500120330) or Tri-Cut Blade w/Glide Cup (99944200030), 1 - Lower Fixing Plate, 1 - 10mm L.H. Nut, 1 - 2x22mm Split Pin.

- 3. Install upper plate (D) on splined shaft. Blade installation requires use of Upper Plate (D) with 20mm pilot. Upper plate with 37mm pilot of the SRM-2601 should be retained for use with nylon line head.
- 4. Place Blade (E) over upper plate pilot, install the Lower Plate (F) and 10mm LH nut (G). Tri-Cut Blade (H) is installed with Glide Cup (J).
- 5. Insert Locking Tool (K) through hole in upper plate and notch in gear housing to prevent splined shaft from turning. Tighten nut and secure with Split Pin (L).



## **U-HANDLE INSTALLATION**

Tools Required: 8mm x 10mm Open End Wrench, Screwdriver, 3mm Allen Wrench.

Parts Required: U-Handle/Blade Conversion Kit P/N 99944200520.

- 1. Close choke and remove air filter cover.
- 2. Disconnect ignition stop leads (A).
- 3. Remove inner throttle cable from carburetor swivel (B).
- 4. Remove throttle cable from throttle cable fixture (C).
- 5. Loosen screw (D) and pull drive shaft assembly from clutch case.
- 6. Loosen four (4) rear handle screws and pull rear handle (E) from the drive shaft assembly.
- 7. Loosen four (4) screws and remove Loop Handle (F).
- 8. Position Handle Bracket (G) 15 3/4 inches (400mm) from engine end of drive shaft. Secure with two (2) 6mm x 30mm bolts.
- 9. Install harness hook.











- Install handles in bracket, place clamp top over handles and secure with four (4) 5mm x 35mm bolts (H).
- 11. Secure throttle cable and leads to drive shaft by sliding wedge under harness hook.
- 12. Install drive shaft and align gear box, power head and U-handles. Tighten screw.
- 13. Place throttle cable through fixture (C) and install wire end into large carburetor throttle swivel hole. Check throttle for freedom of movement and that wide open throttle / low idle extremes are adjusted properly. The outer cable must be adjusted by moving the Cable Adjustment Clamp (I). Consult with your Echo Dealer for correct adjustment procedure.
- 14. Connect ignition stop leads (A)
- 15. Balance unit.

a. Put on harness and attach unit to harness.
b. Slide clamp (J) up or down until unit balances with head approximately 2-3" from ground.
c. Tighten clamp screw.